

Determine Dielectric Constant in 1D Microwave Cavity

Yutong Zhao

Jan 15th, 2018


Target

- Determine the complex dielectric constant of different mediums:
 1. NaCl, NH_4NO_3 , KNO_3 , NaNO_3 , KClO_3 (humidity 0-10%)
 2. Mixture of two above (humidity 0-10%)
 3. Al powder
 4. Water
 5. Icing sugar (humidity 0-10%)
 6. Gasoline and diesel

According to DRDC's contract section 6.5

Resonance method

- Frequency shift in 1D cavity:
By writing down transmission matrix:




$$M_1 = \begin{pmatrix} A_1 & B_1 \\ C_1 & D_1 \end{pmatrix} \quad M_s = \begin{pmatrix} \cos(\beta_s l_s) & -i Z_s \sin(\beta_s l_s) \\ -i Z_s \sin(\beta_s l_s) & \cos(\beta_s l_s) \end{pmatrix} \quad M_2 = \begin{pmatrix} A_2 & B_2 \\ C_2 & D_2 \end{pmatrix}$$

$$M_{AB} = M_1 M_s M_2 \rightarrow S_{21}$$

Different sample will influence the M_s matrix $\rightarrow S_{21}$

Experiment setup





Pure materials

1.57mm
Teflon

248mg
icing sugar

459mg
 KClO_3

494mg
 NaCl




Icing sugar sample




NaNO_3 sample

Spectra vs. humidity


459mg KClO_3



248mg icing sugar




309mg NH_4NO_3




complex ϵ_r vs. humidity





Real part



Imaginary part



Mixture: NH_4NO_3 in sugar(dry)



Progress (~ 80%)

Material	Data collection	Data analysis
NaCl	√	√
NH ₄ NO ₃	√	√
KNO ₃	√	√
NaNO ₃	√	√
KClO ₃	√	√
Mixture: icing sugar & NH ₄ NO ₃	√	√
Mixture: KClO ₃ & NH ₄ NO ₃	In progress(40%)	---
Icing sugar	√	√
Al powder	√	√
Gasoline	√	In progress
Diesel	√	In progress
water	√	In progress